

Coolpad ariseTM

User Manual

Table of Contents

A MESSAGE FROM COOLPAD	8
TRADEMARKS AND COPYRIGHTS.....	9
YOUR PHONE	10
FUNCTIONS OF KEYS	11
CONVENTIONS USED IN THIS GUIDE.....	12
1. GETTING YOU STARTED.....	13
<i>Charging the battery</i>	<i>13</i>
<i>Power phone on & off.....</i>	<i>13</i>
<i>Touch screen & typing directions</i>	<i>14</i>
<i>Other touch tips</i>	<i>14</i>
2. MORE BASICS.....	16

<i>How your phone looks</i>	16
<i>Screen-lock security options</i>	17
<i>Changing sound settings</i>	18
<i>Changing other settings</i>	18
<i>Taking screenshots</i>	18
3. PHONE APPS MADE SIMPLE	19
<i>Making a call</i>	19
<i>Answering & redirecting calls</i>	19
<i>Exploring the call log</i>	20
4. TEXTING & KEYBOARD USE	22
<i>Entering & editing text</i>	22
<i>Next-word suggestions</i>	22
5. CUSTOMIZING & USING YOUR ARISE™ PHONE APPS	23

<i>Customizing your Home screen</i>	23
<i>People</i>	24
<i>Setting up & using Gmail</i>	25
<i>Getting familiar with your Email app</i>	25
<i>Controlling your calendar</i>	26
<i>Operating the alarm</i>	27
<i>Managing your downloads</i>	28
6. PHONE SET-UP AND PHONE MANAGEMENT	29
<i>Privacy settings & accounts</i>	29
<i>Managing location settings</i>	30
<i>Managing sound settings</i>	30
<i>Managing screen settings</i>	31
<i>Managing sleep settings</i>	31
<i>Notifications</i>	31

<i>Airplane mode</i>	32
7. WIRELESS NETWORK SETTINGS	33
<i>Turning on Wi-Fi</i>	33
<i>Changing network settings</i>	34
<i>Adding a Wi-Fi network</i>	34
<i>Setting advanced Wi-Fi options</i>	35
8. BLUETOOTH SETTINGS	36
<i>Turning Bluetooth on/off</i>	36
<i>Changing your phone's Bluetooth name</i>	36
<i>Pairing your phone with a Bluetooth device</i>	37
<i>Connecting to a Bluetooth device</i>	38
<i>Unpairing or aligning a Bluetooth device</i>	38
<i>Monitoring your phone's data usage</i>	<i>Error! Bookmark not defined.</i>

9. CREATING & SHARING VIDEOS AND PICTURES	40
<i>Creating a video.....</i>	40
<i>Taking a photo.....</i>	40
<i>Sharing a video or photo</i>	41
10. DATA USAGE SETTINGS	42
<i>Manage your data usage settings.....</i>	42
<i>Setting a data usage limit warning.....</i>	43
<i>Setting your data usage limits.....</i>	43
11. GOOGLE PLAY STORE.....	44
<i>Accessing Play Store</i>	44
<i>Google Play settings</i>	44
12. USB FILE TRANSFERS	46
<i>Windows transfer</i>	46

<i>Mac OS transfer</i>	47
13. OPTIMIZING YOUR PHONE'S BATTERY LIFE	48
<i>Battery settings</i>	48
14. STAY CONNECTED & GET UPDATES	50
15. ARISE™ SPECS & HARDWARE	51
<i>List of In-Box Contents</i>	53
<i>Declaration of Hazardous Substances</i>	54

A Message From Coolpad

Thank you for purchasing your **arise™** mobile phone! Please follow these simple - but *important* - instructions for optimal use of your new phone:

Before using your phone for the first time, please carefully read this User Guide, especially the security information.

Note: Products or services of the vendor or carrier are subject to change within this User Guide without prior notice.

Application features and functions may vary among countries, regions or hardware specifications, and any third-party application malfunctions are the responsibility of those manufacturers.

Exercise caution when editing User Registration Settings as this may cause functional or compatibility problems for which Coolpad will not be responsible.


Most of all, we want you to thoroughly enjoy your new **arise™** phone and get the most out of all of its remarkable features!

Trademarks and copyrights

Copyright © 2014 Coolpad Technologies, Inc. All Rights Reserved. All materials in this document including, without limitation, the design, the text, and any and all marks (unless otherwise indicated) are the property of Coolpad Technologies, Inc. Coolpad and the Coolpad logo are registered trademarks of of Yulong Computer Telecommunication Scientific (Shenzhen) Co., Ltd. Google, Android, Gmail, Hangouts, Google Play, YouTube. Additional related marks are trademarks of Google Inc. Swype is trademarks or registered trademarks of Nuance Communications, Inc.

Attention: Pictures shown are for illustration only and do not represent actual devices.

Your Phone



Functions of Keys

Keys	Functions
Menu key	Enable the menu pop-up.
Home key	Return to the Home screen from an app screen.
Back key	Return to the previous screen.
Volume keys	Adjust the volume of calls, ringtone, music and videos.
Power key	Press to turn off the backlight or re-activate the phone. Press and hold to turn on or off the power.

Note: Menu, Home and Back keys are touch keys.

Conventions used in this guide

- This indicates some important tips of using the phones, such as what to do and what to avoid to keep good condition of the phone.
- ✓ This explores different functionalities of an app or a setting.

Note: This is a note or notification giving you additional information on phone operations.

1. Getting you started

Get off to a running start with your new arise™.

Charging the battery

1. Connect one end of the data cable to the USB/Power Port. This is located at the bottom of your phone.
2. Connect the other end to the travel adapter.
3. Connect the travel adapter to an electrical outlet to fully charge your phone.

- Use the travel adapter that accompanies your phone; using other adapters may damage your phone.
- Charging your phone through a USB cable that is attached to a laptop takes more time than charging it with the travel adapter.

Power phone on & off

- The Power key is located on the upper, right-hand side of your phone. Press and hold the Power key for a few seconds to turn on your phone.

- To turn off your phone, press and hold the Power key for the menu to pop up, and then select **Power off**.

Touch screen & typing directions

1. Tap selected icon or other items in order to select or activate them.
2. To type a message, tap  at the bottom of the Home screen and use the keypad that appears.
3. You can enter messages in either of the following ways:
 - Type letters one by one and choose the correct one as suggested.
 - Swipe between letters on the screen without pausing. Lift your finger when a new word or name is spelled.

Other touch tips

- ✓ Touch and hold an object on your phone screen without lifting your finger, you can then reorganize your apps layout or drag apps to the Home screen.
- ✓ To drag something, touch and hold an object without lifting your finger, then move your

- ✓ finger on the screen until you reach the desired spot.
- ✓ To zoom in/enlarge, double-tap on a screen object (such as Google Maps). Double-tap again to zoom out.
- ✓ Some apps allow you to zoom in or out with two fingers on the screen. That is, pinch your fingers to zoom out, or spread them apart to zoom in.

2. More basics

How your phone looks

1.  Back key: Return to the previous screen.
2.  Home key: Return to the Home screen.
3.  Menu key: Show setting menus.
4. Close or open recent apps: Holding the Menu key opens a list of your recent apps. Tap an app to open it or remove an app from the list by swiping left or right.
5. Start Google search: Touch and hold the Home key to start Google search directly.

Screen-lock security options

1. To lock your phone, press the Power key (on the phone's right side) briefly, and let go.
2. To unlock, press Power key to turn on the screen, let go and slide the Padlock icon to any direction.



Changing sound settings



On the Home screen, tap > > **DEVICE** > **Sound** to change sound settings on your phone. You can adjust the volume by pressing volume keys on the left side of your phone.

Changing other settings



On the Home screen, tap > > **DEVICE** > **Display** to change the brightness or font size settings and customize the wallpaper on your phone.

Taking screenshots

1. Focus on the image so it displays on your phone screen.
2. Press the Power key and Volume Down key at the same time.
3. The image will be auto-saved in Gallery.

3. Phone apps made simple

Making a call

On the Home screen, tap  >  to enter Phone screen.

- Touch  to enter the keypad, and dial a number to call it.
- Tap  to display your recent calls and tap  to return the call.
- Tap  to display your contacts and tap one to call it.
- During a call, you can tap  at the bottom of the screen to hang up.
- Calls can also be made from other widgets or apps that contain your contact information, by simply tapping the phone number.

Answering & redirecting calls

1. The Incoming Call screen pops up when a call comes in, along with the caller ID and other

information you've entered in your Contact Book.

2. Any missed calls are logged in the Call log, along with a notification.
3. Press the Volume Down key on the left side of your phone to mute the ringer.
4. There are various options for when a call comes in. To answer a call, slide  over to the answering key on the right.

You may:

- ✓ Start talking to the caller.
- ✓ Send to voicemail.
- ✓ Send a message by opening quick text responses and select one of them.

Note: To modify these standard text responses, tap  > **Settings > Quick responses.**

Exploring the call log

- The Call log contains your history of calls received, missed or made.

- Tapping the number will reveal more information about the call.
- Tapping  beside the number returns the call.
- In the call details screen, tap  to send a text message.
- Tap  for contact information.
- Tap  to add a new contact.
- To clear call logs, tap  > **Clear call log**.

4. Texting & keyboard use


Entering & editing text

Enter text by using the screen's keyboard. To open your phone's keyboard, simply tap where you want to type.

- Otherwise, some apps will open the keyboard for you.
- To close the keyboard, tap  below the keyboard.

Next-word suggestions

1. Tap where you want to type text.
2. Begin typing a word. Choose one of the words displayed above the keyboard.
3. If you do not want to use those words, type the next word without using the space bar.
4. Your phone will continue to present word choices while you type.



5. Customizing & using your Arise™ phone apps

Customizing your Home screen

1. Go to the Home screen where you want to position an app.
2. Tap 
3. Swipe right to locate an app or widget icon, and hold it until the Home screen comes up.
4. After sliding the icon into place, lift your finger.
 - ✓ To reposition an app or widget icon on the Home screen, touch and hold the icon, and then move it to a new position.
 - ✓ To move an app or widget icon to another screen, hold and swipe it toward the edge of the current screen. After the icon reaches the other screen, move it to a new spot and lift your finger.

People

- The **People** app easily saves all of your important contact information including contact names, numbers and email addresses.
- It also supports lots of other communication operations.
- To search for your contacts, tap  at the lower left corner of the People screen, enter keywords in the search box. The phone system will automatically display the matched results.
- To add a new contact, tap  at the lower right corner of the People screen.
- Enter the contact information and tap **DONE** to save it.



Setting up & using Gmail

1. The **Gmail** app allows you to read and compose emails.
2. On the Home screen, tap  >  to enter the Gmail screen. Here Gmail has various uses. For instance, utilize your Gmail account for signing in to all Google apps & services that include but are not limited to:
 - ✓ Google Play Music
 - ✓ Google Play Store
 - ✓ Google Drive

Getting familiar with your Email app


1. On the Home screen, tap  >  to enter the Email screen. When using it for the first time, you need to enter your email address and password to configure an account.
2. After your email account is configured, you can archive, delete, label, or perform other mail operations.
3. Tap the icon on the left of a mail thread to select it.

4. After opening a mail, swipe left or right to read earlier or later mail conversations.
5. Tap  at the top of your phone screen to manage your mails.
6. On the Email screen, you can tap  > **Settings** to add a new email account.
7. On the Email settings screen, tap an email account and customize your Email settings.

Controlling your calendar

On the Home screen, tap  >  to enter Calendar screen.

- If you have synced your Gmail account, the first time you open the Calendar app on your phone, it will show your current calendar events.



- To modify the Calendar view, choose **Day**, **Week**, **Month** or **Agenda** by tapping on date at the top left of the Calendar screen.
- View event details by tapping an Event.
- Tap a blank square on the Calendar screen and tap  that shows up to add a new event; or tap an existing event to edit it in a new window.

Operating the alarm

On the Home screen, tap  >  to enter Clock screen. Then, tap  to switch to the Alarm tab.

- Tap  and the time displayed to set your alarm.
- Once your alarm is set, you may add a label to it.
- Select the **VIBRATE** check box and choose your ringtone from the **Ringtones** drop-down

list.

Managing your downloads

On the Home screen, tap  >  to enter Downloads screen.

- You can download files from Gmail or other areas.
- On the Downloads screen, tap an item to open it.
- Touch and hold an item and tap  that appears. In the **Share via** drop-down list, select a sharing method to share it.
- Touch and hold an item and tap  that appears to delete it.
- Tap  > **By name**, **By date modified**, or **By size** to sort the downloaded items.

6. Phone set-up and phone management

Privacy settings & accounts

Perform either of the following operations:

- On the Home screen, tap  >  to enter Settings screen. Then, choose **ACCOUNTS > Google > Search > Accounts & privacy.**
- On the Home screen, tap  > **System Settings > ACCOUNTS > Google > Search > Accounts & privacy.**

These settings control your phone's Google Search privacy features and search-related confidentiality selections for your Google account.

Managing location settings



On the Home screen, tap > to enter Settings screen. Then, choose **PERSONAL > Location**.

On the Location screen, you can perform the following operations:

- ✓ Turn on or off the location service.
- ✓ Set **Location mode** to **High accuracy**, **Battery saving**, or **Device only**.
- ✓ View recent location requests
- ✓ Perform Google Location Reporting settings.

Managing sound settings



On the Home screen, tap > to enter Settings screen. Then, choose **DEVICE > Sound**.

- Tap **Volumes**. Swipe the slider of volume levels for sources, such as music, ringtone, or alarms. Alternatively, press the Volume Up or Down keys on the left side of your phone.
- Tap **Phone ringtone**. Choose a desired ringtone for your phone. You can select **Vibrate when ringing** to enhance notifying effects.

Managing screen settings

On the Home screen, tap  >  to enter Settings screen. Then, choose **DEVICE** > **Display** > **Brightness**.

Managing sleep settings

On the Home screen, tap  >  to enter Settings screen. Then, choose **DEVICE** > **Display** > **Sleep**. You can tap one of the options to select.

Notifications

- On top left of your phone, status icons will pop up displaying which apps have sent you notifications.
- For finding notifications, pull the notification shade down from the top.
- Tap  to view your settings for Bluetooth, Wi-Fi, etc.

Airplane mode

On the Home screen, tap  >  to enter Settings screen. Then, choose **WIRELESS & NETWORKS > More... > Airplane mode**.

This mode is ideal for in-flight phone status, where no signal or Wi-Fi is connected.

7. Wireless network settings

Turning on Wi-Fi

1. On the Home screen, tap  >  to enter Settings screen. Then, choose **WIRELESS & NETWORKS > Wi-Fi** to turn Wi-Fi on/off.



Note: If having been connected to a Wi-Fi network, your phone will be auto-connected once locating it.

2. Swipe the Wi-Fi switch to ON for enabling your phone to scan for available Wi-Fi networks. It will show the networks.
3. Tap the name of a desired network to connect, entering your password if necessary.

Changing network settings

Touch and hold the name of a connected network to change the network's settings.

Adding a Wi-Fi network

1. A Wi-Fi network may be added so that your phone will recognize it along with any of its security credentials, and then it will auto-connect.
2. Always add a Wi-Fi network if the network name is not transmitted (SSID), or when you are out of range.
3. Tap  at the bottom right of the Wi-Fi settings screen.
4. Enter the SSID network name and select the correct security mode.
5. Tap **Save**. Your phone will auto-connect to this network whenever you return to its coverage.

Setting advanced Wi-Fi options

On Wi-Fi settings screen, tap  > **Advanced**.

- You will receive Wi-Fi notifications for available networks in your status bar by default. To disregard notifications, clear the **Network notification** check box.
- To save your phone's data usage, your phone will remain connected to Wi-Fi when your screen sleeps.

8. Bluetooth settings

Bluetooth has the capacity to connect several mobile devices at once, enabling superior synchronization while reversing challenges and problems that would otherwise occur. Use Bluetooth to maximize awesome phone capabilities and functions of your Arise™.



Turning Bluetooth on/off

On the Home screen, tap  >  to enter Settings screen. Then, choose **WIRELESS & NETWORKS > Bluetooth** to turn Bluetooth on/off.

Changing your phone's Bluetooth name

Your phone contains a random Bluetooth name which will be visible to other Bluetooth devices during connection attempts. You can change the random name to a more identifiable one.

1. On the Home screen, tap  >  to enter Settings screen. Then, choose **WIRELESS & NETWORKS > Bluetooth** to turn Bluetooth on.
2. Tap **Bluetooth**.
3. On the Bluetooth settings screen, tap  > **Rename phone**.
4. Enter a new name and tap **Rename**.

Pairing your phone with a Bluetooth device

When initially using a new Bluetooth device, it will be necessary to pair it with your phone, which is crucial in order to connect.

Now both devices save the connected record and will auto-connect for you next time.

If the device to pair with isn't contained in the list, ensure that it is turned on and that it is set to be detectable.

1. On the Home screen, tap  >  to enter Settings screen. Then, choose **WIRELESS & NETWORKS > Bluetooth** to turn Bluetooth on.

2. Tap **Bluetooth**. Your phone will begin searching for nearby Bluetooth devices.
3. If your phone stops scanning before your Bluetooth device is ready, tap **SEARCH FOR DEVICES**.
4. Within the list, tap the ID of the Bluetooth device so as to pair with it.
5. Ensure that both devices show the same passkey and touch **Pair**.

Connecting to a Bluetooth device

Now that your phone is paired with a Bluetooth device, they can be connected manually.

1. On the Home screen, tap  >  to enter Settings screen. Then, choose **WIRELESS & NETWORKS > Bluetooth** to turn Bluetooth on.
2. Within the devices list, tap a paired and unconnected device.
3. The list will indicate that the device and the phone are connected.

Unpairing or aligning a Bluetooth device

Some Bluetooth devices have multiple profiles. Profiles can include the ability to transmit your conversations, play music in stereo, or transfer files or other data.

You can select which profiles you want to use with your phone. You can also change the name of the Bluetooth device as it appears on your phone.

1. On the Home screen, tap  >  to enter Settings screen. Then, choose **WIRELESS & NETWORKS > Bluetooth** to turn Bluetooth on.
2. On the Bluetooth settings screen, tap  next to the connected Bluetooth device which you are configuring.
3. Check the choices offered, such as to change the name, to unpair it or to select profiles.
4. When settings are complete, tap  to return to the previous screen.

9. Creating & sharing videos and pictures

Creating a video

1. On the Home screen, tap  >  to enter Camera screen.
2. Tap the icon on the lower left of the screen to expand the list and select .
3. Tap  while using the screen in order to see your video being recorded.
4. Tap  to stop recording.

Taking a photo

1. On the Home screen, tap  >  to enter Camera screen.
2. Tap the icon on the lower left of the screen to expand the list and select .
3. Focus on your subject by looking through your phone screen.

- 4. Tap  to take a picture.

Sharing a video or photo

- 1. On the Home screen, tap  >  to enter Gallery screen.
- 2. Select a video or photo and tap .
- 3. From the drop-down list, select your desired sharing method.

It really is that easy! Your new arise™ makes it that way.

10. Data usage settings

Manage your data usage settings

Here data usage settings for your new **arise™** are described, but they are carrier-specific. The following instructions will assist in tracing data usage, which may help avoid possible additional charges.

Note: Be sure to check with your carrier for further information.

1. On the Home screen, tap  >  to enter Settings screen. Then, choose **WIRELESS & NETWORKS > Data usage** and switch **Mobile data** to **ON**.
2. Here you will see a graph. The vertical white lines present a time period within the data usage phase.
3. Touch and drag the white lines in order to change a data usage time period.
4. Your actual data usage is shown below the graph.

Setting a data usage limit warning

Touch the orange line on its right side and drag it to the point where you wish to receive a data usage warning notification.

Setting your data usage limits

1. On the Home screen, tap  >  to enter Settings screen. Then, choose **WIRELESS & NETWORKS** > **Data usage** and switch **Mobile data** to **ON**.
2. Activate the red line at the top of the graph by selecting the **Set mobile data limit** check box.
3. Touch the red line on its right side and drag it to the point where you wish to set the limit. Your data will automatically switch off when your usage limit has been reached.

11. Google Play Store

Google Play Store is all-in-one entertainment point with music, movies, books and apps on the web.

Accessing Play Store

1. On the Home screen, tap  >  to enter Google Play Store screen.
2. Swipe right from the left edge of the screen for the menu to pop up. This menu displays your content for that part of Google Play.
3. Your Google Play content can be retrieved this way (from the Play Store app) even if you access it through another phone.
4. Sign in to play.google.com to access your entertainment from any location.

Google Play settings

1. On the Google Play Store screen, tap  > **Settings** to change your Google Play settings.
2. The Google Play settings screen enables you to:
 - ✓ Control game & app updates' notifications.
 - ✓ Set auto updates for apps and widgets.
 - ✓ Clear search history.
 - ✓ Manage user controls.

12. USB file transfers

- With a USB cable, you can transfer pictures, music, and other data files between your arise™ phone and your computer.
- For transferring files to Mac OS X, the Android File Transfer application can be utilized. (Refer to instructions below.)

Windows transfer

1. Connect your phone to the computer's USB port. Its USB storage drive will appear on the computer screen.
2. Begin copying files between your phone and the computer.
3. When transfer is complete, eject the phone from Windows before unplugging the USB cable.

Mac OS transfer

1. Install Android File Transfer from <http://www.android.com/filetransfer> and follow the directions. Double-click for first-time use. (Auto-connect will occur thereafter.)
2. Connect your phone to the computer using a USB cable.
3. The Android File Transfer will begin, including a window pop-up showing your phone contents & other pertinent information.
4. Here you can open or close folders, create new folders, and drag files.
5. Disconnect the USB cable upon completion.

13. Optimizing your phone's battery life

Battery settings

Prolong your phone battery life by shutting down apps not in use or not required.

On the Home screen, tap  >  to enter Settings screen. Then, choose **DEVICE > Battery**. Here you may monitor how apps, other data and your phone system all consume battery power. The following are some suggestions for prolonging the battery life of your phone:

- Turn off **Wi-Fi, Bluetooth, or GPS** with the **Settings** app.
- On the Home screen, tap  >  to enter Settings screen. Then, choose **PERSONAL > Location** to access GPS settings.
- Turn off **Navigation** or **Maps** when not in use.
- Dim your phone's screen brightness:  >  > **DEVICE > Display**.
- Consider turning off auto-sync for all apps:  >  > **ACCOUNTS > Google**.

Note: If auto-sync is turned off, you must manually sync to check emails, and related notifications will no longer pop up.

- Assess battery level and usage:  >  > **DEVICE > Battery**.
 - Battery usage for each app is displayed near the bottom of your phone screen.

Note: If you stop some apps or services completely, your phone may not operate properly.

The battery status & battery levels are indicated at the top of your phone screen.

- Get more details by tapping an app. For some apps, you may modify power usage settings, or halt the app entirely.

14. Stay connected & get updates

- ✓ Get updates, user guides and other more information for your arise™ at www.coolpadamericas.com.
- ✓ Discover what's going on right now in cell phone news, trends, techniques & other cool stuff by connecting with us at:



www.facebook.com/user/CoolpadAmericas



www.youtube.com/CoolpadAmericas



www.twitter.com/CoolpadAmericas

15. arise™ specs & hardware**Specifications**

Dimensions	4.85 inches x 2.50 inches x 0.46 inches
Form Factor	Bar, Touchscreen
Antenna	Built-in
Network Mode	CDMA
Camera	Rear camera: 2.0 MP FF
Earphone Jack	CTIA Standard earphone jack

Screen Parameters

Type	Dimensions	Resolution
FWVGA	4 inches	800x480

Accessories

Battery	Battery Type	Lithium Ion Polymer Rechargeable Battery
---------	--------------	--

	Rated Capacity	1600 mAh
	Nominal Voltage	3.7 V

Prompt: The battery capacity changes with battery upgrade.

List of In-Box Contents

No.	Name	Quantity
1	Phone	1
2	Battery	1
3	Travel Charger	1
4	USB Cable	1
5	Warranty Card	1
6	Quick Start Guide	1

Prompt: The accessory items are as per the final transaction. Please contact the dealer for further details.

Declaration of Hazardous Substances

Parts Name	Toxic or hazardous substances or elements					
	Plumbum (Pb)	Mercury (Hg)	Cadmium (Cd)	Chromium VI (Cr(VI))	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)
PCB Board and Accessories	○	○	○	○	○	○
Plastics	○	○	○	○	○	○
Metals	○	○	○	○	○	○
Battery	○	○	○	○	○	○
Other	○	○	○	○	○	○

○: indicates that the content of the toxic or hazardous substance in all homogeneous materials is within the limit of the SJ/T11363-2006 standard.

×: indicates that the content of the toxic or hazardous substance in some homogeneous materials exceeds the limit of the SJ/T11363-2006 standard.



The Environmentally Friendly Use Period of this product is 20 years, as shown by the symbol on the left. The Environmentally Friendly Use Period of replaceable parts, such as battery, may be different from that of the product. The Environmentally Friendly Use Period is valid only when the product is operated under the conditions defined in this User Guide.